

## Applying DurapatchUV is as easy as 1... 2... 3...



**1. Surface should be cleaned, dry, and free of any contaminants. Cut patch into any size you want without exposing to UV / sunlight. Place remaining material back in foil protective bag.**



**2. Remove white backing tape to expose the sticky resin. Apply patch to repair area with sticky side down and press firmly.**



**3. Remove film backing on other side of application and expose to UV or sunlight. Curing times depend on UV intensity between five minutes (sunny) and 50 minutes (cloudy) or use a UV light indoors with a minimum of 51 lumens.**